

FLO-RATION

Instructions for Setting your Equipment

Setting #1: Vertical

- The arms need to be attached to the shroud with clevis pins in the 1st hole from the top of the arms and will be stamped with a #1 at each hole. The arms should be parallel with the shroud.
- This setting requires no adjustment bar on the rear of the frame.

Setting #2: 45 Degrees / Angle Setting

- The arms need to be attached to the shroud with clevis pins in the 2nd and 3rd holes from the top of the arms and will be stamped with a #2 at each hole. The arms should be parallel with the shroud.
- This setting requires the adjustment bar be attached to the 2nd hole from the top of the adjustment bar (approximately 6" down) to the rear adjustment bar brace . This hole will also be labeled with a #2.

Setting #3: Horizontal

- The arms need to be attached to the shroud with clevis pins in the very bottom holes from the top of the arms and will be stamped with a #3 at each hole. The arms should also be perpendicular with the shroud.
- This setting requires the adjustment bar be attached to the 5th hole from the top of the adjustment bar (approximately 24" down) to the rear adjustment bar brace. This hole will also be labeled with a #3.

General Notes:

No adjustments need to be made to the motor assembly in the shroud or on the braces for the arms on top of the frame. All adjustments will be made on the arms at the shroud and at the adjustment bar at the rear of the frame. All adjustments are made with the use of the clevis pins and require no tools!

